



- 1.** For High Wind, insert Wing Support Struts into Inner Pocket.



- 2.** For Low to Medium Wind, insert Wing Support Struts into Outer Pockets.



- 3.** Insert Spreaders (left/right) into T-Connector.



- 4.** Insert opposite end of Spreader into Y-Connector (left/right). Be sure Wing Support Struts are underneath Spreaders.



- 5.** Extend Bridle Line away from the body. Make sure lines are not twisted.



- For added stability, tie Tails to Wing Tips (left/right). In Strong Wind, tie Tails together as shown.