
Assembly Instructions





 Insert Spreader left and right into Wing Connector. Make sure Spreader is completely inserted into Wing Connector, make sure Spreaders are straight, not bowed.



Insert Spreader left and right into Connector.



 Pass Tail Spreader under Spine and insert into Tail Pocket. (This step may already be completed).



Unwind SkyStream

 Unwind SkyStreamers™ and for more stability, tie them together.

 Attach the QuikClip® to Bridle Loop. Top Loop for light to medium winds, Bottom Loop for strong winds.



Elying Instructions

- 1. Always find a location that is open and free of buildings or trees.
- 2. With your back to the wind, release your kite into the air.
- 3. Let the line out slowly while occasionally tugging to gain altitud
- 4. For an assisted launch, have a friend hold your kite 75 feet / 22.8 meters downwind and release your kite.
- ${\bf 5. \, Pull \, in \, line \, to \, gain \, altitude \, and \, release \, slowly \, for \, more \, distance.}$

Kite Safety



Never fly in thunderstorms.



Never fly over people.



Never fly near overhead power lines. Never try to retrieve your kite from power lines. Call your local power company for assistance.



Never fly near



Never fly near busy streets.

WARNING!

Do not fly near overhead power lines.