




Assembly Instructions

1. Insert Large Spreader into Connector (A) on each wing. Then insert opposite end into (B).
2. Insert Leading Edge Spreader into Connector (C).




3. Secure Velcro Pocket (D).




4. Position Tail Spreader (T) under Spine and insert into Pocket (E).




5. Position Head Spreader under Spine and insert into Pocket (F).



6. (Light wind conditions only) Insert Small Spreader into Connector (G) then Pocket (H).



7. Attach the QuikClip® to the Bridle Loop.



8. For more stability, tie SkyTails® together as shown.

Flying Instructions

1. Always find a location that is open and free of buildings or trees.
2. With your back to the wind, release your kite into the air.
3. Let the line out slowly while occasionally tugging to gain altitude.
4. For an assisted launch, have a friend hold your kite 75 feet / 22.8 meters downwind and release your kite.
5. Pull in line to gain altitude and release slowly for more distance.

Kite Safety



Never fly near tall buildings or trees.



Never fly over people.



Never fly near an airport.



Never fly in thunderstorms.



Never fly near overhead power lines. Never try to retrieve your kite from power lines. Call your local power company for assistance.



Never fly near busy streets.

WARNING!
Do not fly near overhead power lines.