



Back of the Kite




C: Light Wind Pocket


D: Medium to Strong Wind Pocket



Spreader pushed in completely into connector. Connector should look like this



NOT LIKE THIS!!



1. Insert Spreader into Connector (A) (Left & Right).
2. Insert Spreader into Connector (B). (Left & Right)
IMPORTANT: PUSH IN COMPLETELY INTO CONNECTORS!
3. Insert Batten into Outer Pockets if Wind Condition is Light (C).
4. Insert Batten into Inner Pockets if Wind Conditions are Medium to Strong (D).
5. Attach QuikClip® to the Bridle Loop (Front of the Kite)
Top Loop: For Light to Medium Wind Conditions
Bottom Loop: Strong Wind Condition
REMOVE RUBBERBANDS FROM TAILS.
6. For more stability, tie tails together.



LAUNCHING - ASSISTED LAUNCH

- The kite requires a minimum wind of 8 mph / 11.3 kph. Let out approximately 75 feet / 22.9 m of line and have an assistant hold the kite.
- With your back to the wind, release the kite and take a few steps backwards, the kite will rise into the air. Tug line to gain altitude, let out line to gain distance.
- For storage, reverse assembly steps and place into package. Store your kite in a cool dry place. Excessive heat and/or sunlight can damage the package and kite.

KITE SAFETY

WARNING! Do not fly near overhead power lines.
WARNING! Do not use near overhead power lines or during thunderstorms.
WARNING! Not suitable for children under 3 years due to small parts.
WARNING! Not suitable for children under 3 years due to long cord.
Please remove all packaging material before giving the toy to child.
Keep important information for future reference.

Never fly near an airport.
Never fly over people.
Never fly in thunderstorms.
Never fly near busy streets.
Never fly near overhead power lines.

Never try to retrieve your kite from power lines.
Call your local power company for assistance.