

Assembly instructions










- Insert Top Spreaders (left and 2. right) into Top Connector.
- Fold over and secure Velcro
 Flaps over Top Spreaders
 (Left and Right).
- Connect Cross Spreaders (Left and Right). Keep Cross Spreaders on top of Spine.







- 4. Connect Bow String.
 First Loop: Light Winds.
 Second Loop: MediumWinds.
 Third Loop: Strong Winds.
- Remove rubber band from Tails.
- 6. Attach the QuikClip* to Bridle Loop. Top Loop for light to medium winds, Bottom Loop for strong winds.





- 1. Always find a location that is open and free of buildings or trees.
- 2. With your back to the wind, release your kite into the air.
- 3. Let the line out slowly while occasionally tugging to gain altitude.
- 4. For an assisted launch, have a friend hold your kite 75 feet / 22.8 meters downwind and release your kite.
- 5. Pull in line to gain altitude and release slowly for more distance.

Kite Safety



Never fly near tall buildings or trees.



Never fly in thunderstorms.



Never fly over people.



Never fly near overhead power lines. Never try to retrieve your kite from power lines. Call your local power company for assistance.



never fly near an airport



Never fly near busy streets.

WARNING!

Do not fly near overhead power lines.